
Adaptor Installation for ST510 & ST1510

Scope

This application note is to be used for ST510 and ST1510 pressure transducer when mating transducers with adaptor assembly.

Procedure

- 1) Press Teflon o-ring over transducer element seating it against flange.



- 2) Insert Transducer into adapter until seated.



3) Insert retaining nut into backside of adaptor.



4) Torque retainer nut to 100 in-lbs.

